

INSTRUCTIONS FOR THE MC760T TANNING FILTER



THIS FILTER IS INTENDED FOR COLLECTING OVERSPRAY FROM SPRAY TANNING
This machine can be used in conjunction with a booth or tent.

Each unit is supplied with a specialised tanning filter enclosed in a metal frame.

If used in a portable booth, the machine should be placed on the floor OUTSIDE of the booth at the back. If the hole in the booth does not close down enough to fit snugly around the machine you will need to purchase a set of 'wings' – these are a pair of panels to stop the overspray going out the back of the booth. When using the wings, loosen the filter grill knobs and slide the panel slot under the knob and tighten, making sure the panel is now facing forward so that the plastic knobs are behind the panel.

THE FILTER MEDIA SHOULD BE WASHED DAILY IRRESPECTIVE OF THE NUMBER OF TANNING SESSIONS COMPLETED PER DAY

Washing the filter pad: Loosen the grill knobs and remove the metal frame. Do not remove the filter pad from the metal frame when cleaning the filter; just wash under the tap until clean. Leave to dry thoroughly before putting back in the filter machine. It is best to have a spare spray frame and filter to use whilst one is drying.

Changing the filter pad: To replace the filter pad, loosen the grill knobs and remove the metal frame. When replacing the filter media with a new filter pad make sure that the more open (coarser) cell of the filter material is facing outwards and the closed (finer) cell side is facing the inside of the mesh grill.

Using two hands move the bottom of the “V” spring wire to one side until the tip of the V clears the frame and then lift the V out. Remove the filter pad and replace with a new one. Once the new filter material is in position replace the metal V spring.

If you need to wipe the machine over, ensure the machine is NOT plugged into the power. Only use a damp warm cloth, do NOT soak the machine.

Microclene Australia, PO Box 517, Riverwood. NSW. 2210. Ph: 02 9584 8273 Fax: 02 9533 2223
patcarey@ceechem.com.au

Microclene Australia
Cleaning the air you breathe.