

## INSTRUCTIONS FOR THE NSF100



This machine is for use on the nail workstation for removal of dangerous nail dust particles and fumes associated with acrylic nail application.

Place the machine on the worktop to one side of the nail technician and the client, about 300mm (12") away from the hands being worked on.

Turn the machine on (on/off switch located at the rear of the machine).

For ease of use in the nail salon, filters for the NSF100 are provided in cartridge form.

To replace the filter, gently lift and remove the cartridge from the machine. Dispose of used cartridge to waste and place new filter into the machine ensuring the "airflow arrow" is pointing to the rear of the machine. The white dust filter faces the front.

**For best filtration the filter should be replaced monthly.**

**REMEMBER TO WEAR YOUR FACEMASK WHILST PERFORMING THIS TASK**

**Microclene Australia**  
Cleaning the air you breathe.