

INSTRUCTIONS FOR THE MC760T Air Filter



This unit is supplied with a 2 metre power cord and can be used free standing or mounted on the ceiling or wall.

Use the four brackets on the back of the machine to mount it to the ceiling or wall of the work space. These brackets can be swivelled around to obtain the best support for the machine e.g. to mount the filter upright or horizontal on a wall it would be best to turn the fixing brackets to the vertical position.

Before using the unit, it is advised to do a quick test to help you determine when the filter pad needs replacing.

Turn the filter on when in fixed position, place this instruction sheet over the grill area, leave for 30 seconds and then switch the machine off. Then time how long it takes for the paper to fall away from the grill. Repeat this test weekly until the paper falls away in half the original time. For example, if the first test took 15 seconds and after a lot of use it now takes 7 seconds, it is time to change the filter pad.

TO CHANGE THE FILTER PAD: Loosen the easy release knobs on the side of the machine but **DO NOT** completely undo the knobss that hold the grill in place. Lift off the grill, remove old filter pad and place new one in its place. Make sure filter pad is seated properly on top of filter cavity. Replace grill over the pad; tighten knobs to secure grill in place.

If a **CARBON FILTER** is being used it must be placed **BEHIND** the primary white G4 dust filter pad. Life expectancy of carbon filter will depend upon individual user's type and quantity volatile compound usage.

REMEMBER TO WEAR YOUR FACEMASK WHILST PERFORMING THIS TASK

Microclene Australia
Cleaning the air you breathe.